

---

# Instructions

---

## for the installation of the bin top kit, KBT39 onto bin B842

**Applications: 22" wide x 24" deep flake or nugget ice machine centered on bin top.**

1. Uncrate the bin.
2. Install the legs.
3. Open up K kit, it will contain two filler plates with insulation attached, two mounting straps and a tube of food grade RTV sealant
4. Place a filler plate on each end of the bin. The filler plates are built so one is for the left end and one is for the right end. Position them so that the attached insulation fits inside the bin's liner. Secure each at the back with one 5/16" bolt from the kit.
5. Drill three 1/8" dia holes thru the bin's outside panel using the holes in the flange of each filler plate as a template. Do NOT drill beyond the outside panel.
6. Attach the side of each filler plate to the bin with three #8 sheet metal screws from the kit.
7. Place ice machine centered between the two filler plates.
8. Secure ice machine to the bin with the straps from the kit and the bolts from the ice machine's hardware bag.
9. Seal the edges of the ice machine to the filler plates with the RTV sealant.

---

**Note: Sealant fills any gap between ice machine base and filler plate.**

---

